



INSTRUCTIONS FOR USE

Recommended use

1. In traditional and microwave ovens, dishwasher, refrigerator and freezer.
2. Wash the mould before first use.


Do not use

1. On top of stove (electric and ceramic hob, gas burner...).
2. Do not put hot dish on cold/wet surfaces or cold liquids in hot dish.
3. Do not use metal sponges, sharp objects or abrasive powders.

TECHNICAL DATA

Material	Borosilicate glass
Colour	Transparent / light blue

BENEFIT LINE



PLUS LINE

