


# CERAMICA



## Instructions for use

1. Wash the mould before the first use.
2. Slightly grease inside surface with oil, butter or margarine before baking.
3. Do not put the product in an oven pre-heated directly from the freezer (wait until it is at room temperature or warm it up with the oven).
4. Allow cake to cool down a little before removing from the mould.

## Attention



Usable in traditional or microwave ovens



Dishwasher safe



Use oven gloves while using the article in the oven



In compliance with norms which regulate the use of materials for food contact



The mould can be use in the fridge and in the freezer



Please do not use sharp objects or others metal tools which could damage the baking pan surface



Please avoid direct contact with the flame or with the electric plates



Please do not exceed 250° C

**Guardini**

When passion takes shape.