

# RICORRENZE - MOULDS



## Instructions for use

1. Wash the mould before the first use.
2. Slightly grease inside surface with oil, butter or margarine before baking.
3. Allow cake to cool down a little before removing from the mould.
4. For the cleaning of the mould after use, hand-wash with dish soap and dry the mould immediately after washing.

## Attention



OVEN

Use only in traditional ovens (no microwave)



OVEN GLOVES

Use oven gloves while using the article in the oven



In compliance with norms which regulate the use of materials for food contact



Please do not use sharp objects or others metal tools which could damage the baking pan surface



GAS

Do not use on a flame or other direct heat source, including stove tops



Please do not exceed 190° C



DISHWASHER

Don't use the dishwasher



All Guardini steel moulds with non-stick coating are PFOA and heavy metal free



All Guardini steel moulds with non-stick coating are BPA free

# Guardini

When passion takes shape.